

Thank You

for purchasing Westcott gear!

Register your new gear.

We have a simple form for registering your Westcott purchase that provides you with added assurance for your gear: fjwestcott.com/warranty

Visit fjwestcott.com

- Video Tips
- Product Support
- Knowledge Base
- Product Reviews
- Contests & More!

Our promise to you is supported by a commitment to offer the most innovative solutions, exceptional product quality and first class service and support.



WARRANTY

One year against manufacturer defect.

Westcott's warranty obligations for this product are limited to the terms set forth below: The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the "Westcott" trademark, trade name, or logo affixed to them.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (b) to damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) to a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) to cosmetic damage, including but not limited to scratches, dents and broken plastic.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the ONE (1) YEAR limited warranty will be returned at the expense of the sender.

Register this product at FJWESTCOTT.COM/WARRANTY

Repair Dept.: **800-886-1689** / 419-243-7311 (International)

E-Mail: INFO@FJWESTCOTT.COM SUBJECT: ATTN: REPAIR DEPT.

Shipping: F.J. Westcott Co, 1425 Holland Rd, Maumee, OH 43537

©F.J. WESTCOTT CO. ALL RIGHTS RESERVED.



QUICK START GUIDE



SETUP & USAGE



SKYLUX™ WITH BUILT-IN TILTER BRACKET



SILVER REFLECTOR



20' POWER CORD



METAL BALLAST & CARRY CASE




PROTECTIVE TRAVEL CAP

- 1 Remove all contents from the box. Ensure that both the metal ballast and the Skylux are in the OFF position.



Loosen the smaller of the two knobs located on the built-in tilter bracket.



Place the open end of the tilter bracket on the stud of your light stand and tighten the same smaller knob to secure the Skylux to your light stand.



Plug the 3-prong male power plug into the nearest wall outlet. Plug the female end of the same cord into the Skylux ballast.

In the next step, ensure to align the dimple inside of the metal ballast and Skylux connection points with the cutout on the cord's 5-pin connector for proper fitment.



Plug one end of the circular 5-pin power connector into the Skylux ballast and rotate the silver ring clockwise on the cord connector to secure the cord to the metal ballast. Plug the opposite end of the cord into the rear connection point on the Skylux and rotate the silver ring clockwise to secure the cord to the back of the unit.



the handle and rotate the cover counterclockwise.



The included silver reflector and any modifiers equipped with a Bowers S-Type mount, including the Westcott® Rapid Box™ XL & XXL, can be mounted to the front of the Skylux. Umbrellas and portable modifiers that are built on an umbrella frame (i.e. Westcott Apollo™, Halo™, etc.) can be mounted using the umbrella mount located inside the Skylux tilter bracket.

- 8 Supply power to the Skylux by turning the ballast ON. Use the controls located on the rear of the Skylux to turn the unit ON/OFF and adjust the light intensity.

CAUTION

Failure to read & follow the following bullet points may potentially VOID Westcott's 1-year Limited Warranty.

- The Skylux ballast is restricted to use with the Skylux ONLY. The Skylux ballast was designed specifically for use with the Skylux. Failure or attempting to operate the Skylux without the ballast could result in permanent damage to the Skylux and/or poor light output.
- Do not use third party power cables or ballasts with the Skylux.
- Do not use near or submerge in water.
- Do not expose to extreme weather conditions.
- Please use caution when handling the Skylux. Although LED's produce minimal heat when being used, the electronics to power them do require proper ventilation. The front area around the Skylux may become warm during extended usage, especially when enclosed inside a non-ventilated modifier. Improper ventilation could permanently damage the internal components of the Skylux, which may result in VOIDING the 1-year Limited Warranty.
- Avoid pressing or puncturing the front diffusion panel of the Skylux unit as it may result in permanent damage to the LED panel.
- Always TURN OFF the Skylux and metal ballast when not in use. Unplug all power cords and store in a safe place when not in use.