

Setup Instructions

Collapsible Backgrounds

Style Series: 5606, 5641, 5647, 5662, 5664, 5666, 5680, 5681, 5682, 5683, 5684, 5685, 5686, 5687, 5690, 5990, 5986, 5987, 5988, 6741, 6746, 6747, 6760, 6766, 6767, 6768, 6769, 6770, 6771, 6772,

Description

Collapsible backgrounds are perfect for head and shoulders portraiture and deposition-type videos and are available in many colors. The 3' x 4' are available in 2 styles, the 2 in 1 Chroma-key or solid gray and the 5' x 6' and 6' x 7' are available in 2 styles, the single sided and the 2 in 1 in both muslin and Chroma-key. The 2 in 1 backgrounds offer 2 complimenting yet totally different looks in one background. The background can be positioned vertically or horizontally. For quick and easy set-up and teardown, they are also collapsible.

Product Contains

- [1] Collapsible Background
- [1] Clear PVC Storage Bag

FOLDING INSTRUCTIONS

1. Holding the panel/background in front of you, bend one corner of the panel downwards and away from you towards the opposite corner, folding it almost in half (shape should now look like a taco)
2. Holding the two corners together with one hand, use the other to grab one side towards the mid fold (fingers pointing downward)
3. Pull that side towards your body making your palm turn upward.
4. Then switch hands and pull the other side in the same way.
5. Fold in these two corners, one over the other and the top corner will automatically fold itself down underneath them both forming 3 small circles. (Fig. 2)
6. If the collapsed panel will not easily go into the bag use both hands to ensure that the three loops of spring steel are approximately the same size and it should then go in easily.
7. Store somewhere that is not too damp.

